



# RFID AC DUPLIKATOR

## NIŽE, U ORIGINALU

RFID Access Copier 125KHz 13.56MHz Duplicator Card Copier

Material: ABS; Frequency | LF: 125/250/375/500/625/750/875/1000KHZ | HF: 13.56MHz ISO14443A

Battery: 3V 4pcs AAA | Dimension: 152x80x21mm



+381 11 355 7599  
+381 63 598 017  
office@aspekt.rs

**NAČIN KORIŠĆENJA, NIŽE U ORIGINALU****How to use?**

1. Open the machine with the top left button.
2. Press "OK" to confirm the note.
3. Press "Mode" to choose frequency.
4. Touch the card or key fob to read or write or input ID number  
Copy: read one tag, and touch other tag to write. (the other tag should be writable)  
Input: press number, then touch a tag to write.(the tag should be writable)
5. Finish

**DETALJNA TEHNIČKA SPECIFIKACIJA U ORIGINALU**

Material	ABS
Dimension	152x80x21mm
Frequency	LF: 125/250/375/500/625/750/875/1000KHZ HF: 13.56MHz ISO14443A
Battery	3V 4pcs AAA
Operating temperature	0°C~60°C
Storage temperature	0°C~60°C
Weight	200g
Range	2~5cm
Display	LED
Language	English
Power support	USB
Operating system	Windows 98, ME, NT, 2000, XP, 2003, Vista
	Windows XP x64, 2003 x64, Vista x64
	Linux
	Mac 10.5. Mac 10.6
	WinCE 5.0 (Windows embedded Compact)



+381 11 355 7599  
+381 63 598 017  
office@aspekt.rs